


Tube No.
105SD©

Di-iso-PROPYL AMINE



1. PERFORMANCE

- 1) Measuring range : 1-16ppm
Number of pump strokes : 1(100mL)
- 2) Sampling time : 1 minute/1 pump stroke
- 3) Detectable limit : -
- 4) Shelf life : 3 years
- 5) Operating temperature : 15 ~ 25°C
- 6) Reading : Graduations printed on the tube are calibrated by Ammonia at 1 pump stroke and Di-iso-Propyl Amine concentration is determined by using a conversion chart at 1 pump stroke.
- 7) Colour change : Pale purple → Pale Yellow

2. RELATIVE STANDARD DEVIATION

RSD-low : 10% RSD-mid. : 5% RSD-high : 5%

3. CHEMICAL REACTION

By reacting with Phosphoric acid, PH indicator is discoloured.



4. CALIBRATION OF THE TUBE

PERMEATION TUBE METHOD

5. INTERFERENCE AND CROSS SENSITIVITY

Substance	Interference	Coexistence
Amines	Similar stain is produced.	Higher readings are given.

