
# **CYCLOHEXANOL**



## 1. PERFORMANCE

1) Measuring range 5-500 ppmNumber of pump strokes  $2(200 \text{m} \ell)$ 

2) Sampling time : 3 minutes/2 pump strokes

3) Detectable limit  $\therefore$  2 ppm 4) Shelf life  $\therefore$  2 years 5) Operating temperature  $\therefore$  10  $\sim$  40  $^{\circ}$ C

6) Temperature compensation : Necessary (See "TEMPERATURE CORRECTION TABLE")
7) Reading : Direct reading from the scale calibrated by 2 pump strokes

8) Colour change : Yellow→Pale blue

## 2. RELATIVE STANDARD DEVIATION

RSD-low: 10 % RSD-mid.: 10 % RSD-high: 10 %

#### 3. CHEMICAL REACTION


Chromium oxide is reduced.  $C_6H_{11}OH + Cr^{6+} + H_2SO_4 \rightarrow Cr^{3+}$ 

# 4. CALIBRATION OF THE TUBE

GAS CHROMATOGRAPHY

## 5. INTERFERENCE AND CROSS SENSITIVITY

Substance		Interference	Coexistence		
Aliphatic hydrocarbons		Whole reagent is changed to Pale brown.	The accuracy of reading is not affected.		
Aromatic hydrocarbons		"	"		
Halogenated hydrocarbons		"	"		
Alcohols	FIG.1	Similar stain is produced.	Higher readings are given.		
Esters		Pale ringed stain is produced near the bottom of the reagent.	The accuracy of reading is not affected.		



#### TEMPERATURE CORRECTION TABLE

Scale	True Concentration (ppm)								
Readings 10°C (50° F		15℃ (59*F)	20°C (68°F)	25℃ (77°F)	30°C (80°F)	35℃ (95°F)	40°C (95°F)		
500	_	_	500	380	280	210	160		
400	_	520	400	300	230	170	130		
300	_	400	300	220	170	130	100		
200		270	200	140	110	90	70		
100	230	140	100	90	70	50	40		
50	90	70	50	40	35	20	15		
30	50	40	30	25	18	14	10		
10	18	13	10	8	6	4	2		
5	9	7	5	4	3	2	1		