

1. PERFORMANCE


- 1) Measuring range : 20-500 ppm
Number of pump strokes : 1 (100mℓ)
- 2) Sampling time : 1.5 minutes/1 pump stroke
- 3) Detectable limit : 5 ppm
- 4) Shelf life : 2 years
- 5) Operating temperature : 0 ~ 40 °C
- 6) Temperature compensation : Necessary (10 ~ 40 °C) (See "TEMPERATURE CORRECTION TABLE")
- 7) Reading : Graduations printed on the tube are calibrated by Methyl methacrylate at 1 pump stroke and Allyl alcohol concentration is determined by using a conversion chart.
- 8) Colour change : Pale yellow → Pale blue

2. RELATIVE STANDARD DEVIATION

RSD-low : 15 % RSD-mid. : 10 % RSD-high : 5 %

3. CHEMICAL REACTION

Chromium oxide is reduced.



4. CALIBRATION OF THE TUBE

GAS CHROMATOGRAPHY

5. INTERFERENCE AND CROSS SENSITIVITY

Substance	Interference	Coexistence
Alcohols	Similar stain is produced.	Higher readings are given.
Ethers	∕	∕
Paraffin hydrocarbons (more than C ₃)	Whole reagent is changed to Brown.	∕
Aromatic hydrocarbons	∕	∕
Esters	∕	∕
Ketones	∕	∕
Halogenated hydrocarbons FIG.1	∕	∕




FIG.1 Influence of 1,1,1-Trichloroethane

TEMPERATURE CORRECTION TABLE

Scale Readings (ppm)	True Concentration (ppm)				
	0 °C (32 °F)	10 °C (50 °F)	20 °C (68 °F)	30 °C (86 °F)	40 °C (104 °F)
500	—	600	500	430	380
400	—	480	400	350	300
300	480	360	300	260	230
200	320	240	200	170	150
100	240	120	100	90	80
50	80	60	50	43	38
20	32	24	20	17	15

