

- ★ READ CAREFULLY THIS INSTRUCTION MANUAL AND THE INSTRUCTIONS OF THE ASPIRATING PUMP PRIOR TO USING THIS PRODUCT.
- ★ DON'T DISCARD THIS INSTRUCTION MANUAL UNTIL ALL TUBES IN THIS BOX ARE USED UP.

1. PERFORMANCE:

Measuring Range	: 0.1 - 0.2 %	0.2 - 2.0 % ^(*)
and Sampling Time	: 7 minutes (2 pump strokes)	3.5 minutes (1 pump stroke)

^(*) Graduations on the detector tube are based on 1 pump stroke.

Colour Change	: White → Dark Brown
Detectable Limit	: 0.08 % (2 pump stroke)
Operating temperature	: 0-40 °C (32-104°F) (No correction is necessary.)
Aspirating Pump	: Model AP-20, AP-20S, 400B, AP-1, AP-1S or 400A

CAUTION

1. DETECTOR TUBE CONTAINS REAGENTS.
2. DO NOT TOUCH THESE REAGENTS DIRECTLY ONCE TUBES ARE BROKEN.
3. KEEP THE TUBES OUT OF THE REACH OF CHILDREN.

NOTICE

1. USE ONLY PUMP MODELS AP-20, AP-20S, 400B, AP-1, AP-1S OR 400A. OTHERWISE, CONSIDERABLE ERROR IN INDICATION MAY OCCUR.
2. BEFORE TESTING, CHECK THE ASPIRATING PUMP FOR LEAKS (**REFER TO ITEM 8 INSPECTION OF ASPIRATING PUMP**). ANY PUMPS SHOWING SIGNS OF LEAKAGE SHOULD BE CORRECTED BEFORE USE.
3. DO NOT USE THIS TUBE OUTSIDE THE STATED OPERATING TEMPERATURE RANGE.
4. STORE TUBES IN A COOL AND DARK PLACE (0-25 °C/32-77°F), AND USE BEFORE EXPIRATION DATE PRINTED ON TOP OF THE BOX.
5. PRIOR TO USE, READ CAREFULLY **ITEM 9. USER RESPONSIBILITY**.
6. READ THE CONCENTRATION IMMEDIATELY AFTER MEASUREMENT.

2. SAMPLING AND MEASUREMENT:




Fig.1

NOTE: POST-TREAT TUBE SHOULD BE CONNECTED BETWEEN A DETECTOR TUBE (I) AND ASPIRATING PUMP IN ORDER TO REMOVE GENERATED HARMFUL GAS.

- ① Break both ends of a new detector tube (I) and a post-treat tube (II), and connect each end of the detector tube and post-treat tube with rubber tube as shown in Fig 1.

CAUTION SAFETY GLASSES AND GLOVES SHOULD BE WORN TO PREVENT INJURY FROM SPLINTERING GLASS.

- ② Insert the post-treat tube into the aspirating pump securely as shown in Fig.1. (Arrow mark shall point to the pump.)
- ③ Align the guide marks on the handle and stopper of the aspirating pump.
- ④ Pull the pump handle at full stroke until it locks and wait for 3.5 minutes or until the completion of sampling is confirmed with the flow indicator of the pump (See descriptions about the flow indicator in the instructions of the pump).
- ⑤ On completion of sampling, read the scale at the maximum point of the stained layer.
- ⑥ In case of 2 pump strokes, turn the handle to right or left at 1/4 turn and push back it thoroughly without removing the detector tube from the pump, and then align the guide marks again as shown step ③ and repeat step ④.
- ⑦ In this case, actual concentration is half of the reading value.

- SPECIAL NOTE:** I. The scale is calibrated at 20 °C (68°F), 50 %R.H. and 1013hPa. Readings obtained in other circumstances should be corrected (**REFER TO ITEM 3. CORRECTION FOR AMBIENT CONDITIONS**).
- II. When the maximum point of the stained layer is unclear or oblique, read the scale at the centre between the longest and shortest points.

3. CORRECTION FOR AMBIENT CONDITIONS:


- ① Temperature; No corrections is necessary.
- ② Humidity; No corrections is necessary.
- ③ Atmospheric Pressure;

$$\text{True concentration} = \text{Tube reading} \times \frac{1013}{\text{Atmospheric pressure (in hPa)}}$$

4. INTERFERENCES:

Trichloroethylene produces a yellow stain and gives higher readings. 1,1,1-Trichloroethane and 1,2-Dichloroethylene or Vinyl chloride produces an orange stain and gives higher readings. Carbon tetrachloride does not affect readings. Aromatic hydrocarbons produces a dark brown stain and do not affect readings. Carbon monoxide produces a brown stain and gives higher readings.

5. CHEMICAL REACTION IN THE DETECTOR TUBE:



6. DISPOSAL OF TUBE:

USED TUBES SHOULD BE DISPOSED CAREFULLY ACCORDING TO RELEVANT REGULATIONS, IF ANY.

7. HAZARDOUS AND DANGEROUS PROPERTIES OF TETRACHLOROETHYLENE:

- TLV-TWA. ◆ : 25 ppm
- Explosive range in air : —
- ◆ Threshold Limit Value established by the American Conference of Governmental Industrial Hygienists, 2006.

8. INSPECTION OF ASPIRATING PUMP:

Checking for leaks;

- ① Insert sealed, unbroken detector tube into the pump.
- ② Align the guide marks on the shaft and stopper of the pump.
- ③ Pull the handle to full stroke and wait for 1 minute.
- ④ Unlock the handle and allow it to return slowly into the pump by holding the cylinder and handle securely.

CAUTION HANDLE WILL TEND TO SNAP BACK INTO THE PUMP QUICKLY.

- ⑤ If the handle returns completely to the original position, the performance is satisfactory. Otherwise, refer to maintenance procedure in the instruction manual of the pump to correct the leakage.

9. USER RESPONSIBILITY:

It is the sole responsibility of the user of this equipment to ensure that the equipment is operated, maintained, and repaired in strict accordance with these instructions and the instructions provided with each Model AP-20, AP-20S, 400B, AP-1, AP-1S or 400A aspirating pump, and that detector tubes are not used which are either beyond their expiration date or have a colour change different to that stated in the Performance specifications.

The Manufacturer and Manufacturer's Distributors shall not be otherwise liable for any incorrect measurement or any damages, whether damages result from negligence or otherwise.